


# 4 button Joystick Latch


Marc Center  
FRC3548 coach

Why cannot I see the 10 point  
button select on the Driver Station  
but all other cases?


Periodic Loop  
100 msec rate




Stacked  
Sequence





Periodic Loop  
100 msec rate



## Stacked Sequence



I cannot see this case on the Driver Station



I can see all other cases on the Driver Station

