

F) Linksys Gaming Adapter

Default IP:
192.168.1.250

Default Username: admin

Default Password: admin

Select "Basic" from the menu across the top of the webpage.

Select "Wireless" to open the configuration page for the wireless settings. The configuration page is shown below:



Change the "Wireless Network Name" to your FRC Team Number, no quotation marks.

Configure all other settings to match those shown above. a. NOTE: When using the WRT160N the "802.11 Band" option should be set to 2.4GHz

Click "Save Settings"

When asked to reboot now or later, choose "Reboot Now"

Login again (same username/password)

Select "Basic" from the menu across the top of the webpage.

Select "Network Settings" to open the configuration page for the wireless settings. The configuration page is shown below: